

Heatmiser Senior

Engineers Set-up Guide

Revision 1




This product should be installed by a qualified electrician.
Improper installation may result injury, death or property damage.

Inside Front Cover Blank

Contents

<i>Description</i>	<i>Page</i>
Keypad Layout	1
Standard Terms	1
Initial Setup	2
Boiler Setup	3-4
Optimiser Zone Setup	4
Compensator Zone Setup (With Internal Sensor)	5
Compensator Zone Setup (No Internal Sensor)	6
Timer Zone	6
Vent Zone Setup	7
Inputs Explained	7
Normal Run Mode Screen	7-9
Sensor Calibration	9
Title Setup	9
Viewing Zone Setup	10
Altering Zone Setup	11
Comms Setup	11
User Code Setup	11
System Reset	12
Wiring Diagrams	13-16

1. Heatmiser Senior Keypad



Soft Keys

The Heatmiser Senior features “soft keys” which can be seen above down each side of the LCD. If you have used a cash machine, you will be familiar with soft keys. The benefit of soft keys is that the button text is displayed on the LCD and is constantly changed as you use the control. This removes the need for dual purpose buttons which can be confusing.

Navigating the Zones

Pressing the Left and Right arrow keys allows you to scroll through the zones set-up on your system.

Display Back Light

To assist with programming the system, the backlight is permanently on.

2. Standard Terms

Self Learning Optimisation is a system whereby the Heatmiser control will automatically calculate the start up time to ensure the building is up to temperature for the programmed comfort level. It does this by monitoring the internal temperature readings, so that for example in milder weather conditions heat up times are reduced – thus saving energy. The Heatmiser Senior only optimises on the 1st switching level of each day.

Compensation is a system whereby the Heatmiser monitors the internal temperature according to the preset slope setting in the control. By monitoring the internal and external temperatures the Heatmiser can calculate the flow temperature needed to maintain the programmed room temperatures.

Pump Overrun: To help dissipate the heat from the boiler, a pump overrun time can be set for each zone. When enabled, the pump will run on for a number of minutes (programmable) after the zone has switched off.

Alarm/Override Inputs: The Heatmiser Senior has 5 inputs which can be used as zone overrides or alarm input. When set as an override, the zone will override on/off when the inputs is made or broken. The alarm input mode makes the Heatmiser Senior flash an alarm message on screen when the input is made.

Preheat is the number of hours the control can come on before the programmed switching time (when in optimising mode)

Rate of Change is the time it takes to raise the building 1°C. The factory default for this setting is 20 minutes but the control will automatically adjust this according to the fabric of the building.

3. Initial Set-up Procedure

This initial set-up guide has been designed to help you set-up the control to suit your installation.

When setting up the Heatmiser Senior you must first set-up the Boiler zone and then any other zones thereafter.

Apart from the Boiler zones, there are 4 other types available;

Opt: The control will automatically calculate the start up time to ensure the building is warm by the start of the programmed switching time; it does this by monitoring the internal temperature and adjusting the amount of preheat required.

Comp: Compensator. The control will automatically calculate the flow temperature required to maintain room temperature. By monitoring the internal and external sensor temperatures, the flow temperature can be increased or decreased to suit demand. This calculation is worked from a slope factor which can be altered on screen. The slope factor is set to 03 as factory default, which means that for every 1°C rise in outside temperature the flow temperature is decreased by 3°C.

Timer: In this mode, the Heatmiser will simply work to the programmed times – and is not dependant on any temperature settings.

Vent: In this mode, the Heatmiser works in reverse to a normal heating zone. In other words, the output is active when the actual temperature rises above the programmed temperature.

Begin Here . . .

- To run the set-up procedure, press Program, enter the **Engineers Code of 6343** and press OK.
- Select Initial Set-up
- Confirm that you wish to proceed with the set-up routine
Note: This will delete all previous set-up data

Boiler Zone Set-up

- A. Boiler Flow Sensor?
- a. If you have a boiler flow sensor on the pipe-work, answer YES and go to step B.
 - b. If you do not have a boiler flow sensor on the pipe-work, answer NO and go to step E.

B. Fixed or Variable – Select fixed if you require a fixed flow temperature. One reason to select this option is if there is a hot water zone. Select variable if you wish the Heatmiser Senior to calculate the flow temperature (compensate) depending on the external temperature.

You should now set-up the following parameters according to whether you selected Fixed or Variable.

C. Fixed Flow Boiler Parameters

Feature No	Parameter	Typical	Description
1.	Pump Overrun	20 minutes (00 disabled)	The Pump Overrun is used to dissipate the heat from the system
2.	Fixed Flow	80°C	This is the flow temperature that will be maintained when there is a heat demand.
3.	Flow Frost	08°C	Should the flow temperature drop below this setting, even with no demand, the boiler(s) will fire.

- When you have set-up the settings listed above, you need to press OK

D. Variable Boiler Zone Parameters

Feature No	Parameter	Typical	Description
1.	Pump Overrun	20 minutes (00=disabled)	The Pump Overrun is used to dissipate the heat from the system
2.	Flow Frost	08°C	Should the flow temperature drop below this setting, even with no demand, the boiler(s) will fire.
3.	Compensation Slope	03	For every 1°C rise in outside temperature, the flow will be decreased by the “slope setting”
4.	Minimum Flow	40°C	This is the minimum flow setting that will be allowed by the control
5.	Maximum Flow	80°C	This is the maximum flow setting that will be allowed by the control
6.	Hysteresis	02	This is the number of degrees above the flow set temperature that the boilers will be turned off.

- When you have set-up the settings listed above, you need to press OK

E. No Boiler Flow Sensor Parameters

Feature No	Parameter	Typical	Description
1.	Pump Overrun	20 minutes (00=disabled)	The Pump Overrun is used to dissipate the heat from the system

- When you have set-up the settings listed above, you need to press OK

Notes:

- When you have set-up a zone on the Heatmiser Senior, you will be shown a display with the relay outputs and sensor input details. Make a note of these and confirm this is how you have wired this particular zone.
- The settings above are typical; you should confirm that they are suitable for your installation.

Next Zone . . .

You are now prompted to set-up another zone or if you have finished configuring the Heatmiser Senior, press Finish.

We have detailed the different zone types available and their parameters below. After each new zone, confirm the wiring outputs are correct as per the information screen displayed.

The Heatmiser Senior will automatically calculate how many relays you have used and will only offer zone types which can be set-up on the Senior with the relays and sensor connections remaining.

Optimiser Zone Set-up

When you have selected Optimisation, you are prompted to enter the following parameters.

No	Parameter	Typical	Description
1	Enable the Boiler ?	Yes (Press 1) No (Press 0)	When enabled, the boiler will be enabled when there is a demand for heat from this zone.
2	Pump Overrun	20 minutes	The Pump Overrun is used to dissipate the heat from the system
3	Preheat Time	03 Hours	Maximum number of hours the heating can come on before the programmed time.
4	Rate of Change	20 minutes / °C	Number of minutes to raise the building 1°C
5	Hot Water Boost	Yes (Press 1) No (Press 0)	When enabled, the Hot water output is activated for 1 hour at
6	Apply Summer (Follows the Summer Input when made)	Yes (Press 1) No (Press 0)	If enabled, when the summer input is made, the zone will switch into System Frost temp Normally disabled for HW zones
7	Override Limit	08 Hours	This limits the amount of hours the zone can be overridden
8	Override Input	Yes = Override Input (Press 1) No = Alarm Indication (Press 0)	To enable an override input for this zone, select Yes here. For an alarm indication, select No.
9	External Off	Enter the Ext Off Temp	Should the external temperature rise above this temperature, the zone will be turned off
10	Average Sensor	Yes (Press 1) No (Press 0)	In large areas, 2 sensors can be used to take an average temperature reading.

- When you have set-up the settings listed above, you need to press OK

Compensator Zone

The Heatmiser Senior asks you to select the zone **with or without an internal sensor**.

With an internal sensor, the Heatmiser Senior compensates the flow temperature only when the Room temperature is within 2°C of the set temperature. Without an internal sensor, the Heatmiser Senior compensates whenever there is a demand for heat.

When you select a compensator zone, you are prompted to enter the following parameters.

Compensating with an Internal Sensor

No	Parameter	Typical	Description
1	Enable the Boiler	Yes (Press 1) No (Press 0)	When enabled, the boiler will be enabled when there is a demand
2	Pump Overrun	20 minutes	The Pump Overrun is used to dissipate the heat from the system
3	Preheat	03 hours	Maximum number of hours the heating can come on before the programmed time
4	Rate of Change	20 minutes per °C	Number of minutes to raise the building 1°C
5	Flow Frost	08°C	Should the flow temperature drop below this setting, even with no demand, the boiler(s) will fire.
6	Compensation Slope	03	For every 1°C rise in outside temperature, the flow will be decreased by the "slope setting"
7	Minimum Flow	According to your system	This is minimum flow setting that will be allowed by the control
8	Maximum Flow	80°C	This is the maximum flow setting that will be allowed by the control
9	Pulse Time	15 seconds	This is the number of seconds the Senior will signal to open or close the valve
10	Delay Time	150 seconds	This is the number of seconds the Senior will wait after pulsing the valve.
11	Apply Summer Input	Yes (Press 1) No (Press 0)	If enabled, when the summer input is made, the zone will switch into System Frost temp
13	Override Limit	08 hours	This is the maximum override time allowed
14	Override Input	Yes = Override input (Press 1) No = Alarm indication (Press 0)	To enable an override input for this zone, select Yes here. For an alarm indication, select No.
15	External Off	Enter the Ext Off Temp	Should the external temperature rise above above this setting, this zone will switch off
16	Average Sensor	Yes (Press 1) No (Press 0)	In large areas, 2 sensors can be used to take an average temperature reading.

- When you have set-up the settings listed above, you need to press OK

Compensating with no Internal Sensor

No	Parameter	Typical	Description
1	Enable the Boiler	Yes (Press 1) No (Press 0)	When enabled, the boiler will be enabled when there is a demand
2	Pump Overrun	20 minutes	The Pump Overrun is used to dissipate the heat from the system
3	Flow Frost	08°C	Should the flow temperature drop below this setting, even with no demand, the boiler(s) will fire.
4	Compensation Slope	03	For every 1°C rise in outside temperature, the flow will be decreased by the “slope setting”
5	Minimum Flow	40	This is minimum flow setting that will be allowed by the control
6	Maximum Flow	80	This is the maximum flow setting that will be allowed by the control
7	Pulse Time	15 seconds	This is the number of seconds the Senior activate to open or close the valve
8	Delay Time	150 seconds	This is the number of seconds the Senior will wait after pulsing the valve.
9	Apply Summer Input	Yes (Press 1) No (Press 0)	If enabled, when the summer input is made, the zone will switch into System Frost temp
11	Override Input	08	To enable an override input for this zone, select Yes here. For an alarm indication, select No.
12	Override Limit	Yes = Override input (Press 1) No = Alarm Indication (Press 0)	Should the external temperature rise above this setting, this zone will switch off
13	External Off	Enter the Ext Off Temp	Should the external temperature rise above this setting, this zone will switch off

- When you have set-up the settings listed above, you need to press OK

Timer Zone

The Heatmiser Senior allows you to set-up a timer zone. In this mode, the user has 4 switching periods per day available. When you select a Timer Zone you are prompted to enter the following parameters.

Feature No	Parameter	Typical	Description
1	Enable the Boiler	Select Yes or No	When enabled, the boiler will be enabled when there is a demand
2	Apply Summer	Select Yes or No	If enabled, this zone will switch into summer mode when the summer input is made
3	Override Input	Yes = Override Input No = Alarm Indication	To enable an override input for this zone, select Yes here. For an alarm indication, select No.
4	Override Limit	08 hours	Should the external temperature rise above this setting, this zone will switch off
5	External Off	Enter the Ext Off Temp	Should the external temperature rise above this setting, this zone will switch off

- When you have set-up the settings listed above, you need to press OK

Vent Zone

The Heatmiser Senior allows you to set-up a vent zone. In this mode, the user has 4 switching periods per day available. When you select a Vent Zone, you are prompted to enter the following parameters.

Feature No	Parameter	Typical	Description
1	Apply Summer	Select Yes or No	If enabled, this zone will switch into summer mode when the summer input is made
2	Override Input	Yes = Override Input No = Alarm Indication	To enable an override input for this zone, select Yes here. For an alarm indication, select No.
3	Override Limit	08 hours	Should the external temperature rise above this setting, this zone will switch off
4	Average Sensor	Select Yes or No	Should the external temperature rise above this setting, this zone will switch off

- When you have set-up the settings listed above, you need to press OK

Inputs Explained

Inputs 1-3 are reserved as zone override or alarms depending on their configuration.

Input 4 is reserved as the Holiday Input. When this input is made, all of the zones will control to the System Frost temperature. See the User Manual for more information.

Input 5 is reserved as the Summer Input. When this input is made, all of the zones programmed to follow this input will control to the System Frost temperature. It is normal for hot water zones to have this input disabled. You can do this by selecting “No” to the question Apply Summer Input during configuration.

4. Normal Mode Screen Layouts

The screens displayed on your Heatmiser Senior are determined by how it was initially set-up.

Boiler Enable Screen

This screen shows:

1. The current time and date
2. The pump and boiler enable status.
3. Note that on this screen there is only 1 menu button “Program”

Wednesday		15.12	16-08-06	23°C
Program	<div>Pump Status Off</div> <div>Boiler Enable Off</div>			

Boiler Screen

This screen shows:

1. The current time and date
2. The Flow Actual and Set temperatures
3. The Pump and Boiler status
4. Note that on this screen there is only 1 menu button “Program”

Wednesday	15.12	16-08-06	23°C
Program	BOILERS FLOW TEMPERATURE ACTUAL SET 75°C 80°C PUMP STATUS ON BOILER STATUS ON		

Optimiser Zone

This screen shows:

1. The current time and date
2. The actual and set temperatures
3. The heat and pump status
4. Menu Options as displayed

(The pump status will only be displayed if a pump overrun time has been set-up)

Wednesday		15.12	16-08-06	23°C
Program	ZONE 1			Override
	TEMPERATURE			
	ACTUAL	SET		
	20°C	22°C		
	PUMP STATUS			
	ON			
	HEAT STATUS			Holiday
	ON			

Compensation Zone

This screen shows:

1. The current time and date
2. The actual and set flow temperatures
3. The actual and set room temperatures
4. The Pump and Valve status
5. The alarm status
6. Menu Options as displayed

Wednesday		15.12	16-08-06	23°C
Program	ZONE 2			Override
	FLOW TEMPERATURE			
	ACTUAL	SET		
	70°C	80°C		
	ROOM TEMPERATURE			View
	ACTUAL	SET		
	20°C	18°C		
	PUMP OFF			Holiday
VALVE WAITING				
HEAT OFF				
ALARM: CLEAR				

Timer Zone

This screen shows:

1. The current time and date
2. The Timer status
3. The alarm status
4. Menu Options as displayed

Wednesday		15.12	16-08-06	23°C
Program	ZONE 3			Override
	FLOW TEMPERATURE			
	ACTUAL SET			
	70°C 80°C			
	ROOM TEMPERATURE			View
	ACTUAL SET			
	20°C 18°C			
	PUMP OFF			Holiday
VALVE WAITING				
HEAT OFF				
ALARM: CLEAR				

Vent Zone

This screen shows:

1. The current time and date
2. The actual and set room temperature
3. The vent status
4. Menu Options as displayed

Wednesday	15.12	16-08-06	23°C
Program	ZONE 4		Override
	ROOM TEMPERATURE		
	ACTUAL	SET	
	20°C	18°C	
	STATUS		View
	VENT ON		
	ALARM: CLEAR		Holiday

5. Zone Set-up Complete

You have now completed to set-up the zones within the Heatmiser Senior.
You now need to calibrate each sensor connected to the Heatmiser Senior.

6. Sensor Calibration

Each sensor connected to the Heatmiser Senior should be calibrated to ensure the reading is accurate. We suggest you wait 1 hour after installation before calibrating.

You should have taken an accurate temperature reading from a digital thermometer for each zone prior to beginning the calibration process.

To calibrate the sensor, follow the steps below:

- Press Program, enter the **Engineers Code of 6343** and press OK
- Select Zone Set-up
- You need to work through each zone, so highlight the boiler zone and press OK
- Select Sensor Cal from the menu
- You will now see the current sensor readings (all sensors for this zone are shown on one screen) For the Boiler zone, the flow sensors and external sensors are shown.
- You should now enter, using the numeric keypad, the calibrated reading.
- Select OK to confirm
- Press Back and then repeat this process for each zone

7. Title Set-up

You are able to program titles for a) Each Zone, b) Each Relay and c) Each Alarm This allows you to easily identify each zone on the system.

Note: The Boiler zone titles cannot be customised.

Zone Title

A zone title of up to 12 characters can be programmed.
To customise the zone title, follow these steps:

- Press program, enter the Engineers code **6343** and press OK
- Select Zone Setup
- Highlight the zone you wish to alter, and press OK
- Select Titles
- Select Zone Title
- Using the Heatmiser keypad, you can enter the desired title.
- Press OK to store

Relay Title

A Relay title of up to 12 characters can be programmed.

To customise the relay title, follow these steps.

- Press Program, enter the Engineers code 6343 and press OK
- Select Zone Setup
- Highlight the zone you wish to alter, and press OK
- Select Titles
- Select Relay Title
- Using the keypad, you can enter the desired title.
- Press OK to store
- OR
- Move the cursor to the end of the Relay Title, and you will notice the cursor jumps down to the Pump Title (if on the system) You can enter this title in the same way
- Using the keypad, enter the desired title
- Press OK to store

Alarm Title

An alarm title of up to 12 characters can be programmed.

To customise the alarm title, follow these steps.

- Press program, enter the Engineers code and press OK
- Select Zone Setup
- Highlight the zone you wish to alter, and press OK
- Select Titles
- Select Alarm Title
- Using the keypad, you can enter the desired title.
- Press OK to store

8. Set-up Complete

The Heatmiser Senior is now set-up and is ready for use.

You should now consult the User Operators Guide for information on how to operate the product.

9. Viewing the Zone Set-up

Once you have configured the Heatmiser Senior you can view the setting for each zone by following the steps:

- Press Program and enter the configuration code (6343)
- Select Zone Set-up
- You can now select the zone you wish to view
- Select View Config

You will then be presented with the configuration screen which will display the settings for the zone selected.

Note: You are unable to alter any setting on this screen, it is for viewing only.

Wednesday	15.12	16-08-06	23°C
	1.	ENABLE THE BOILER	Y
	2.	PUMP OVERRUN	00M
	3.	PREHEAT	03H
	4.	RATE OF CHANGE	20M
	5.	HOT WATER BOOST	N
	6.	APPLY SUMMER	N
	7.	OVERRIDE LIMIT	08H
	8.	OVERRIDE INPUT	N
	9.	EXTERNAL OFF	00C

10. Altering a Zone Set-up

Once you have configured the Heatmiser Senior you are able to change any of the zone parameters, but you are not able to make changes to say the number of zones or add additional sensors etc..

If you are looking to make significant changes to the set-up of the control, you must run the Initial Setup Procedure – this is to ensure the product is configured properly therefore removing any risk of conflict.

To adjust the configuration of a zone, follow the steps below.

- Press Program and enter the configuration code (6343)
- Select Zone Set-up
- You can now select the zone you wish to view
- Select Re-Config
- You can make any adjustments necessary
- Press OK to save

11. Comms Setup

When the Heatmiser Senior is used as part of a network system, a unique communication address must be entered.

12. User Code Reset


Should you forget the User code, you can use this feature to reset it.

- Press Program, enter the Engineers code **6343** and press OK
- Select Code
- The Heatmiser Senior will display the Old User code
- You can now enter a new code using the keypad
- And press Confirm to store


13. System Reset


Should you need to reset the Heatmiser Senior back to the factory defaults, you can do so by using this function. You should note that all your settings will be lost after resetting the Senior.


	Common to all sensors	Common to all sensors	valve / pump Zone 4	valve / pump Zone 3	valve / pump Zone 2	valve / pump Zone 1	Switched live to boiler
+							



CONNECTING ALARM AND REMOTE OVERRIDE INPUTS







Back Cover Blank