

Heatmiser Quick Guide

Step By Step Instructions To Alter Any Of The Sections Below

Programming switching times

- Press PROG
- Type User Security Code
- Press ENTER
- Press 2 for Data
- Type Start Time for Monday Period 1
- Press ENTER
- Type End Time for Monday Period 1
- Repeat if further switching times are required - (Max 3 periods per day)
- Press RUN to return to the Normal Run Mode

Altering Temperature Settings

- Press PROG
- Type User Security Code
- Select 1 for Temp
- Type the required day temperature (e.g. 22°C)
- Press ENTER
- Select 1 if you require Frost Protection or 2 if you do not
- Enter, if required, the Frost setting (e.g. 08°C)
- Press ENTER
- Press RUN to return to the Normal Run Mode

Overriding the Heatmiser

- Press the OVERRIDE key
- Enter User Security Code
- Press ENTER
- Press 1 to enter the Override mode
- Select either 1 or 2 to override the zone ON(1) or OFF(2)
- Now enter the required Override period (eg 02 for 2 hours)
- Press ENTER

Setting the Time & Day

- Press PROG
- Type User Security Code
- Select 3 for Time
- Enter the current Time (e.g. 07.00)
- Press ENTER
- Now press 1-7 to set the current day (e.g. 1 - Mon, 7 - Sun)
- Press RUN to return to the Normal Run Mode

Note:

- 1) 24 Hour Clock Notation should be used when programming the Heatmiser.
- 2) All Switching times should be actual occupancy times, no warm up period is needed.